



for USB,  
supply 5v  
separately

SD Card  
Write Protect (WP) and  
Card Detect (CD) not  
connected

n/c do gnd clk vss gnd di cs

To PIC pin 4

To PIC pin 26

To PIC pin 6

To PIC pin 14

16  
3V